

A control circuit is inside the top of the handle. It is driven by a battery





**pull out the top
part of the handle**

Pull out three rubber cushion and unscrew three screws inside



Open the cover. Please note there are two springs inside. It could jump out. Don't lose it.





This is the circuit board



This is a battery



**Alkaline 12V Batteries L1028
(A23, GP23A, MN21, LRVO8)**