

Supplemental Manual of Steam Mop

Model: ST-1501

Technical Data:

110V, 1500W, 60Hz, Water Tank Capacity: 375/75mL, Duration: 25Min

The multi-functioning steam mop for the floor also works as a portable steam iron for your clothes.


Safety:

1. Keep out of reach of children.
2. Make sure voltages are compatible before using.
3. Do not leave machine plugged in when filling the water tank. After use, empty the water.
4. Keep the mop vertical or horizontal to prevent water from splashing out. Do not rotate, invert or shake while in use.
5. Shut off the power and unplug the mop when there is no water inside the tank to prevent dry heating (which will shorten the mop's life).
6. Do not use chemicals, perfume, vinegar, starch or detergent in the water tank.
7. Do not spray directly on the human body, pets or plants to prevent burns.
8. Do not use the machine on wet surfaces.
9. When using the machine, make sure the power cord is unwinded and not touching any other items.
10. Do not use near flammable items or near heat sources.
11. If defective or damaged, send the machine back to the company. Do not throw it out.

Before and After Use:

1. If the water quality in your area is very hard, it is recommended to add distilled water to the tank. The performance and service life of the product will improve greatly.
2. Dry the water tank after use to prevent impurities from clogging the tank pipe.
3. If the water tank's water level is low, unplug the power before refilling the tank.
4. If water spills for the steam nozzle, check if:
 - The power plug is properly plugged in
 - The power socket is working correctly
 - Whether the switch button is in the heating/pressing gear
5. Do not use steel wool, abrasive cleaners or corrosive liquid to clean the steam mop. After the product is fully cooled, simply clean it with a damp cloth and non corrosive liquid detergent.
6. Store the mop in a dry place.

Package




Parts:

Steamer with steam mop water tank (pink)



3 additional mop bottom accessories, from left to right: first two for hard floors, rightmost plastic cover for carpet (add that on top of the soft pads). The default pad included is blue.



Attach pads via velcro while snap on for plastic carpet cover.



Mop with steamer.



Closed pink lid.



Back of mop with water tank.



Steam ironing accessories. Cloth hanger, brush for tougher fabrics (snap on), smaller water tank for steam ironing.



Attached steam iron brush.

Steam Mop Use:

For cleaning carpets and wooden floors, use the steam mop water tank (375mL).

1. If using the mop on rough surfaces or carpets, install the plastic head cover to allow easier gliding. If using the mop on tiles, smooth surfaces, you can use the mop as is (with just blue cloth). To snap on the water tank, push the tank down lightly and slide it up until it clicks. To remove water tank, press and hold the bottom white circle and slide it out. To remove the handle bar, use a sharp object to press in on the snap hole and pull handle out.
2. With 375mL of water, the mop can typically function for 25 minutes continuously.
3. Once plugged in to the power supply, the light will be lit. The steam ironing machine will begin to heat up, and the light will remain on for about 35 seconds. Once the light goes out, toggle the gear to "drag". At this time, the drag head will start emitting steam and you may begin using the mop.
4. Drag back and forth on the floor for at least 8 seconds until the area is clean.
5. Do not leave the mop on the same place on wooden/carpet or else the floor surface will be damaged.

Ironing Use:

*Only use the ironing water tank when ironing.

1. Once plugged in to the power supply, the light will be lit. The steam ironing machine will begin to heat up, and the light will remain on for about 35 seconds. Once the light goes out, you can begin to use it.
2. The enclosed brush cover can enhance the infiltration of the steam on thicker fabrics. Make sure you install the brush before plugging in the machine.
3. The steam iron can be used on horizontal/vertical hanging clothes. The included suction and clothes hanger can be used on smooth surfaces (ceramic tiles, glass, doors). The hanger can handle up to 5kg or 11lbs.